

STEEL TECHNICAL DATA

- INSTALLATION RECOMMENDATIONS
- MATERIAL SPECIFICATIONS
- SIZING CHARTS
- TOOLS & ACCESSORIES









POLEENFORCER®


U.S. Patent No. 5,383,749

PoleEnforcer's® patented full length taper and flange design ensures that the steel unit maintains contact with the pole below grade, thereby transferring the load back into sound material in the pole butt below grade. These features result in the strongest, most effective reinforcement available on the market today. Because of its superior design, PoleEnforcer® units can be used to reinforce poles that have been determined to be rejects, resulting in significant cost savings.

Complete pneumatic and drop weight tool systems can be purchased or rented from LWS. For sizing and ordering information visit www.lwsinc.com.



POLEENFORCER® TECHNICAL DATA




			PoleE	NFORCER® ST	RENGTH C	HART				
	PoleEnforcer® Unit Number				Unit Dimensions Width Length Thickness (in) (ft) (in)			E D* Embedment Depth (ft)	A G Above Ground (ft)	Unit Weight (Lbs.) Single Unit
	■PE - 27 - 10	27,600	55,200	15,000	5.500	10	0.1875	5.0	5.0	85
	PE - 37 - 10	37,900	75,800	22,000	6.250	10	0.1875	5.0	5.0	101
	PE - 51 - 10	51,000	102,000	28,000	7.375	10	0.1875	5.0	5.0	115
	PE - 58 - 10	58,600	117,200	30,000	7.750	10	0.1875	5.0	5.0	124
lee	PE - 73 - 10	73,500	147,000	35,000	9.000	10	0.1875	5.0	5.0	136
0 St	7 - 10 - 5	78,300	156,600	49,000	7.000	10	0.3125	5.0	5.0	180
Grade 80 Steel	8 - 11 - 5	91,700	183,400	56,000	8.000	11	0.3125	5.5	5.5	210
Grad	9 - 11 - 4	85,200	170,400	47,000	9.000	11	0.2500	5.5	5.5	179
926	9 - 11 - 5	108,000	216,000	62,000	9.000	11	0.3125	5.5	5.5	222
30ksi A-656	9 - 11 - 6	128,600	257,200	72,000	9.000	11	0.3750	6.0	5.0	266
30ks	10 - 11 - 5	123,700	247,400	69,000	10.000	11	0.3125	6.0	5.0	234
	10 - 11 - 6	148,100	296,200	80,000	10.000	11	0.3750	6.0	5.0	286
	11 - 11 - 6	169,500	339,000	87,000	11.000	11	0.3750	6.0	5.0	294
	12 - 12 - 6	191,500	383,000	95,000	12.000	12	0.3750	6.0	6.0	337
	13 - 12 - 6	211,500	423,000	103,000	13.000	12	0.3750	6.0	6.0	352

All PoleEnforcers are hot dip galvanized per ASTM A-123 specifications. *Longer lengths or SRS® units are available for higher decay applications.

800-949-3526

3

PoleEnforcer® Technical Data



PHASERAISER® TEST... "ZERO THIN SHELL"

Tests conducted on the patented PhaseRaiser® structure lifting system (the design of which is based on the patented PoleEnforcer®) proved the remarkable strength of the PoleEnforcer® in thin shell applications. The test simulated the equivalent of 8'-0" of ZERO SHELL THICK-NESS.





50'-0" Class 3 Pole

Pole

Failure.....3,550 lbs

Loaded....48'-0" AGL

Groundline Moment

Failure..... 170,400 ft-lbs

No permanent deformation of steel.

PoleEnforcer® + Crossbolts = PhaseRaiser®



	NESC Grade B & C Construction - Per NESC Rule 250B & C/D Restoration Factors (67% & 75%)													
	Required PoleEnforcer - Semi Thin Shell - (Single or Double Units)													
Pole						Pol	e Class							
Length	H6	H5	H4	Н3	H2	H1	1	2	3	4	5	6	7	9
20 ft.							PE-51-10	PE-37-10	PE-37-10	PE-27-10	PE-27-10	PE-27-10	PE-27-10	PE-27-10
25 ft.							PE-58-10	PE-51-10	PE-37-10	PE-37-10	PE-27-10	PE-27-10	PE-27-10	PE-27-10
30 ft.							PE-73-10	PE-58-10	PE-51-10	PE-37-10	PE-37-10	PE-27-10	PE-27-10	PE-27-10
35 ft.					10-11-5	9-11-5	9-11-4	PE-73-10	PE-58-10	PE-51-10	PE-37-10	PE-27-10	PE-27-10	
40 ft.			12-12-6	11-11-6	10-11-6	10-11-5	9-11-5	9-11-4	PE-73-10	PE-58-10	PE-51-10	PE-37-10		
45 ft.	10-11-6D	10-11-5D	9-11-5D	12-12-6	11-11-6	10-11-6	10-11-5	8-11-5	PE-73-10	PE-58-10	PE-51-10	PE-37-10		
50 ft.	11-11-6D	10-11-6D	10-11-5D	13-12-6	12-12-6	10-11-6	10-11-5	9-11-5	9-11-4	PE-73-10	PE-58-10			
55 ft.	12-12-6D	11-11-6D	10-11-6D	10-11-5D	13-12-6	11-11-6	10-11-6	10-11-5	8-11-5	PE-73-10				
60 ft.	12-12-6D	11-11-6D	10-11-6D	9-11-6D	9-11-5D	12-12-6	11-11-6	10-11-5	9-11-5	9-11-4				
65 ft.	13-12-6D	12-12-6D	11-11-6D	10-11-6D	10-11-5D	13-12-6	11-11-6	10-11-6	10-11-5	8-11-5				
70 ft.			13-12-6D	11-11-6D	10-11-6D	10-11-5D	13-12-6	11-11-6	10-11-6	9-11-5				
75 ft.			13-12-6D	12-12-6D	11-11-6D	9-11-6D	9-11-5D	12-12-6	10-11-6					
80 ft.				12-12-6D	11-11-6D	10-11-6D	10-11-5D	12-12-6	11-11-6					
85 ft.				13-12-6D	12-12-6D	10-11-6D	10-11-5D	13-12-6	11-11-6					
90 ft.					12-12-6D	11-11-6D	10-11-6D	9-11-5D	12-12-6					
95 ft.					13-12-6D	11-11-6D	10-11-6D	10-11-5D						
100 ft.					13-12-6D	12-12-6D	10-11-6D	10-11-5D						
105 ft.						12-12-6D	11-11-6D	9-11-6D						
110 ft.						13-12-6D	11-11-6D	10-11-6D						
115 ft.						13-12-6D	11-11-6D	10-11-6D						
120 ft.						13-12-6D	12-12-6D	10-11-6D						
125 ft.							12-12-6D	11-11-6D						

D = DOUBLE UNIT | LARGER UNITS AVAILABLE UPON REQUEST

THE POLEENFORCER® PATENTED ADVANTAGE



800-949-3526

PoleEnforcer® Sizing

NESC Grade B & C Construction - Per NESC Rule 250B & C/D Restoration Factors (67% & 75%)

			F	Requirec	l PoleEnt	forcer - 1	Thin She	ell - (Do	uble Un	its Only	7)			
Pole						Pol	e Class							
Length	Н6	H5	H4	Н3	H2	H1	1	2	3	4	5	6	7	9
20 ft.							PE-27-10D							
25 ft.							PE-27-10D							
30 ft.							PE-37-10D	PE-37-10D	PE-27-10D	PE-27-10D	PE-27-10D	PE-27-10D	PE-27-10D	PE-27-10D
35 ft.					PE-73-10D	PE-51-10D	PE-51-10D	PE-37-10D	PE-27-10D	PE-27-10D	PE-27-10D	PE-27-10D	PE-27-10D	
40 ft.			9-11-5D	9-11-4D	PE-73-10D	PE-58-10D	PE-51-10D	PE-51-10D	PE-37-10D	PE-27-10D	PE-27-10D	PE-27-10D		
45 ft.	10-11-6D	10-11-5D	9-11-5D	8-11-5D	7-10-5D	PE-73-10D	PE-58-10D	PE-51-10D	PE-37-10D	PE-37-10D	PE-27-10D	PE-27-10D		
50 ft.	11-11-6D	10-11-6D	10-11-6D	9-11-5D	8-11-5D	7-10-5D	PE-73-10D	PE-51-10D	PE-51-10D	PE-37-10D	PE-27-10D			
55 ft.	12-12-6D	11-11-6D	10-11-6D	10-11-5D	9-11-5D	9-11-4D	PE-73-10D	PE-58-10D	PE-51-10D	PE-37-10D				
60 ft.	12-12-6D	11-11-6D	10-11-6D	9-11-6D	9-11-5D	8-11-5D	7-10-5D	PE-73-10D	PE-51-10D	PE-51-10D				
65 ft.	13-12-6D	12-12-6D	11-11-6D	10-11-6D	10-11-5D	9-11-5D	9-11-4D	PE-73-10D	PE-58-10D	PE-51-10D				
70 ft.			13-12-6D	11-11-6D	10-11-6D	10-11-5D	9-11-5D	9-11-4D	PE-73-10D	PE-58-10D				
75 ft.			13-12-6D	12-12-6D	11-11-6D	9-11-6D	9-11-5D	8-11-5D	PE-73-10D					
80 ft.				12-12-6D	11-11-6D	10-11-6D	10-11-5D	9-11-5D	7-10-5D					
85 ft.				13-12-6D	12-12-6D	10-11-6D	10-11-5D	9-11-5D	9-11-4D					
90 ft.					12-12-6D	11-11-6D	10-11-6D	9-11-5D	8-11-5D					
95 ft.					13-12-6D	11-11-6D	10-11-6D	10-11-5D						
100 ft.					13-12-6D	12-12-6D	10-11-6D	10-11-5D						
105 ft.						12-12-6D	11-11-6D	9-11-6D						
110 ft.						13-12-6D	11-11-6D	10-11-6D						
115 ft.						13-12-6D	11-11-6D	10-11-6D						
120 ft.						13-12-6D	12-12-6D	10-11-6D						
125 ft.							12-12-6D	11-11-6D						


D = DOUBLE UNIT | LARGER UNITS AVAILABLE UPON REQUEST





PNEUMATIC DRIVING SYSTEM

PE90HHB-BD **AIR HAMMER & BRACKET ASSEMBLY**



(A) PE-90-AH (B) PE90HB

(C) PE2118DH

90LB. AIR HAMMER

BRACKET

SHOE & SHANK ASSEMBLY

90 LBS. 22 LBS.

(C) PETR

26 LBS.

PE90WP


18'-6" SECTIONAL WINCH **POLE ASSEMBLY**

(A) PEPY

POLE YOKE

(B) W2000 WINCH

54 LBS. TOTAL





PE90TWB PULL DOWN WINCH ASSEMBLY

(A) W3200 PULL DOWN WINCH (B) PEBR

BRIDAL ROLLER (BLACK)

TENSION ROLLER (WHITE)

10 LBS. 2 LBS.

73 LBS.

PE-90-PDS COMPLETE PNEUMATIC DRIVING SYSTEM TOOL PACKAGE

PE90HHB-BD AIR HAMMER BRACKET ASSEMBLY

PE90WP WINCH POLE ASSEMBLY PE90TWB PULL DOWN WINCH ASSEMBLY

BANDING DISPENSER DH1-2 PEAT2 AIR TENSIONER

PEAS2 **AIR SEALER**

PEBS2 MANUAL BANDING SHEAR PE-FRL FILTER REGULATOR LUBRICATOR (2 EA) 3/8" TOOL HOSE (25 FT. EA.) PE38AH25

PE152RT NYLON RATCHET STRAP

DROP WEIGHT DRIVING SYSTEM

PE-500-DWS DROP WEIGHT SYSTEM (A) PE-25-WW-1B-LT 25LB. WAFER WEIGHTS (10) 25 LBS. EA. (B) PE-250-DS DRIVING SHANK W/ SHACKLE AND EYEBOLT 250 LBS.

BANDING & SEALING TOOLS

PEMT2P MANUAL TENSIONER

3/4" TO 2" PUSH TENSIONER 8 LBS.



PEAT2 AIR TENSIONER

2" AIR TENSIONER 9 LBS.



PEMS2 MANUAL SEALER

2" MANUAL SEALER 11 LBS.



PEAS2 AIR SEALER

2" AIR SEALER 25 LBS.



PEBS2 MANUAL BANDING SHEAR

2" MANUAL BANDING SHEAR 7 LBS.



DH1-2 2" BANDING DISPENSER

2" BANDING DISPENSER 46 LBS.



PEOS2GL GALVANIZED SEALS

2" X 4-1/4" OPEN CRIMP SEAL



SAFETY CAPS

PE2SC CAP W/NAILS (6" TO 9" UNITS)
PE3SC CAP W/NAILS (10" TO 13" UNITS)



PEB2G85ROLL 2" GALVANIZED BANDING

2" X .044" STEEL BANDING 12,000 LBS. Ultimate tensile strength 138,000 PSI





INSTALLATION ACCESSORIES

PE-FRL FILTER-REGULATOR-LUBRICATOR

FILTER-REGULATOR-LUBRICATOR ASSY 6 LBS.



PE38AH25 3/8" TOOL HOSE

25' AIR HOSE ASSEMBLY 5 LBS.




PE 152RT NYLON RATCHET STRAP

10' X 2" RATCHET STRAP 4 LBS.



DRILLING ALIGNMENT TOOL

PE78DJ SMALL ALIGNMENT TOOL ("A"=16") 12 LBS. PE78DJ2 LARGE ALIGNMENT TOOL ("A"=20") 14 LBS.



PEPDW-EXT PULL DOWN WINCH EXTENSION

6' WINCH EXTENSION ASSEMBLY 26 LBS.





ROLLER PLATE (USED DOUBLE UNITS AND W/WINCH EXTENSION) 8 LBS.











SPLICED REINFORCEMENT SYSTEM U.S. PATENT NO. 9,777,500




- SOFT SOIL APPLICATIONS
- CAR DAMAGED POLES
- POLES IN ICE OR WATER
- EXCAVATION NEAR POLE
- ENVIRONMENTALLY



10




TYPICAL APPLICATIONS




SOFT SOIL

PoleEnforcer SRS® units are driven below the pole butt into the good soil to a depth recommended by LWS.



CAR BREAKS

PoleEnforcer SRS® units are driven below grade and extend above grade to a height recommended by LWS.



HIGH DECAY

PoleEnforcer SRS® units are driven below grade and extend above grade to a height recommended by LWS.



U.S. Patent No. 6,115,988 & 6,151,860

Canadian Patent No. 2,252,115 & 2,297,318

INCREASE HEIGHT, CAPACITY, AND REVENUE

Patented in the US & Canada, the PhaseRaiser® Structure Lifting System is the most innovative and economical solution to address conductor clearance points of interest. More than 13,000 energized structures have been safely raised since 1997. A line crew of 5 or 6 can typically raise three structures per day.

The PhaseRaiser® system costs significantly less than a structure changeout, is performed on energized lines, and utilizes low impact equipment. The system utilizes a specialized tool trailer that can be rented or purchased.

To obtain a quote on your next structure upgrade project, fill out the PhaseRaiser® Structure Information worksheet at www.lwsinc.com.



STRUCTURE INFORMATION WORKSHEET


Use this form to provide LWS engineers information regarding your structure and unique lift requirements. LWS can provide a complete computer analysis on your structure(s) and will recommend & supply complete material kits that will: raise, raise and reinforce the ground line, or raise, reinforce and reclassify the poles for each structure. LWS designers may recommend additional X-braces or foundation systems with the material kits.


Complete the following form and send it to LWS at: engineering@lwsinc.com - OR fill out ONLINE at www.lwsinc.com

Customer Information	
Customer Name:	Phone:
Contact Name:	
Project Name:	Email:
Project Address:	Constr Start Date:
City / State:	Delivery Location: City / State / Zip
Structure Type No. of Vee Braces 0 2 4 Send detailed drawing if available H-Frame	Pole Information Pole Height(s): Pole Class(es): Species: Douglas-fir Southern Pine Cedar Pole Condition at Groundline: Inspection Report Available? Yes No
Structure Information Line Voltage:	345kV 230kV 161kV 138kV
Conductor Size:	115kV 69kV Other
Shield Wire Size: Span Length:	Date Line Built:
Lift and Reinforcement Needed NOTE: Illustrations show PhaseRaisers rotated 90° on poles for clarity. Desired Lift (5 to 20ft) Additional Comments (I.E cable TV, Telephone etc.)	Raise Raise/Reinforce

PhaseRaiser® Technical Data

Standard Assembly for "PRH"







Type "PRH" - Raise Only

For H-Frames or other Multiple Pole Structures

Standard Raises are 5', 10', 15' or 20'

"X" = Lift Height

For lifts 0 to 15 feet:

For lifts 16 to 20 feet:



Add additional X-brace to span gap for lifts 16ft or greater. X-BRACE ASSEMBLIES AVAILABLE FROM LWS (ORDERED SEPARATELY).

20 ft. lift - North Dakota

NOTE: Most H-frame strengths are limited by the pole capacity above the X-brace. However, the capacity of the structure after lift needs to be checked either with the use of PLS-POLE or by LWS to determine if additional X-bracing is required.



	MULTI POLE									
	Minimum Unit Size									
Existing		Evicti	na Dolo Class							
Pole		EXIST	ng Pole Class							
Length	H2	H1	1	2	3					
50'-0"	PRH9	PRH9	PRH7	PRH7	PRH7					
55'-0"	PRH10	PRH9	PRH8	PRH7	PRH7					
60'-0"	PRH11	PRH10	PRH9	PRH7	PRH7					
65'-0"	PRH11	PRH10	PRH9	PRH8	PRH7					
70'-0"	PRH12	PRH11	PRH10	PRH8	PRH7					
75'-0"	PRH13	PRH12	PRH10	PRH9	PRH8					
80'-0"	PRH13	PRH12	PRH11	PRH9	PRH8					
85'-0"	PRH14	PRH13	PRH11	PRH10	PRH8					
90'-0"	PRH14	PRH13	PRH12	PRH10	PRH9					
95'-0"	PRH15-80	PRH14	PRH12	PRH10	_					
100'-0"	PRH15-80	PRH14	PRH13	PRH11	_					
105'-0"	PRH15-80	PRH14	PRH13	PRH11	_					
110'-0"	PRH15-80	PRH15-80	PRH13	PRH12	_					

Contact LWS for sizes not shown.



Need - Raise Structure 10'-0" (X=10'-0") Existing Pole - 75'-0" Class 2

—"W" Width of steel

Order - PRH9 - 22L

PhaseRaiser unit size from table above.

"L" Length of steel ("X" + 12'-0") Note: Material to be galvanized. For weathering steel add "W", for painted steel add "P". Example:

PRH9-22L**W** PRH9-22L**P**

All PhaseRaiser® steel Units include mounting hardware, caps, and side shields.


INCREASE HEIGHT, CAPACITY, AND REVENUE


345kV H-frame structure raised 15 feet (lowa)





Standard Assembly for "PRHR"





TYPE "PRHR" - RAISE & REINFORCE

USED WHEN GROUNDLINE DECAY IS, OR COULD BE AN ISSUE & ALL SINGLE POLE APPLICATIONS

"X" = Lift Height

Standard Raises are 5', 10', 15' or 20'

For lifts 0 to 15 feet: "L" = "X" + 12'-0" "A" = 5'-6"

For lifts 16 to 20 feet:

(H-Frames Only) "L" = "X" + 13'-0" "A" = 6'-6" (For lifts 16' - 20' add additional X-brace)

Note: Material to be galvanized. For weathering steel add "W", for painted steel add "P".



	SINGLE POLE										
	Top Unit Minimum Size										
Existing Pole	Existing Pole Class										
Length	H2	H1	1	2	3						
50'-0"	PRH9	PRH9	PRH7	PRH7	PRH7						
55'-0"	PRH10	PRH9	PRH8	PRH7	PRH7						
60'-0"	PRH11	PRH11	PRH10	PRH9	PRH8						
65'-0"	PRH11	PRH12	PRH11	PRH10	PRH9						
70'-0"	PRH12	PRH13	PRH11	PRH10	PRH9						
75'-0"	PRH13	PRH13	PRH12	PRH10	PRH9						
80'-0"	PRH13	PRH14	PRH12	PRH11	PRH10						
85'-0"	PRH14	PRH14	PRH13	PRH11	PRH10						
90'-0"	PRH14	PRH14	PRH13	PRH11	PRH10						
95'-0"	PRH15-80	PRH15	PRH13	PRH12	_						
100'-0"	PRH15-80	PRH15	PRH14	PRH12	_						
105'-0"	PRH15-80	PRH15	PRH14	PRH12	_						
110'-0"	PRH15-80	PRH15-80	PRH14	PRH12	-						

The PRHR system is required for all single pole applications. The system is also used for multi-pole structures where groundline decay is, or could be, an issue.

	Bottom Ui	nit Minimum Size (Embedment depth	= "L" minus 5'-0")							
Existing		Eviating Dala Class										
Pole	Existing Pole Class											
Length	H2	H1	1	2	3							
50'-0"	PRHRB58-11	PRHRB58-11	PRHRB5A6-10	PRHRB5A6-10	PRHRB5A6-10							
55'-0"	PRHRB59-11	PRHRB58-11	PRHRB5A7-10	PRHRB5A6-10	PRHRB5A6-10							
60'-0"	PRHRB510-11	PRHRB510-11	PRHRB59-11	PRHRB58-11	PRHRB5A7-10							
65'-0"	PRHRB510-11	PRHRB511-11	PRHRB510-11	PRHRB59-11	PRHRB58-11							
70'-0"	PRHRB511-11	PRHRB512-11	PRHRB510-11	PRHRB59-11	PRHRB58-11							
75'-0"	PRHRB512-11	PRHRB512-11	PRHRB511-11	PRHRB59-11	PRHRB58-11							
80'-0"	PRHRB512-11	PRHRB513-11	PRHRB511-11	PRHRB510-11	PRHRB59-11							
85'-0"	PRHRB513-11	PRHRB513-11	PRHRB512-11	PRHRB510-11	PRHRB59-11							
90'-0"	PRHRB513-11	PRHRB513-11	PRHRB512-11	PRHRB510-11	PRHRB59-11							
95'-0"	PRHRB614-12	PRHRB514-11	PRHRB512-11	PRHRB511-11	_							
100'-0"	PRHRB614-12	PRHRB514-11	PRHRB514-11	PRHRB511-11	_							
105'-0"	PRHRB614-12	PRHRB514-11	PRHRB514-11	PRHRB511-11	_							
110'-0"	PRHRB614-12	PRHRB614-12	PRHRB514-11	PRHRB511-11	_							

Ordering Example:

Need - Raise Structure 10'-0" (X=10'-0'')

Existing Pole - 75'-0" Class 1

Order - PRHR10 - 22L PhaseRaiser top

unit size from "W" Width of table above.

top steel top unit steel ("X" + 12'-0")

(Consists of two PRH10-22L Top Units and two "L" Length of PRHRB59-11 Bottom Units)

> "W-B" Width of bottom unit steel

Note: Material to be galvanized. For weathering steel add "W", for PRH9-22LW painted steel add "P".


Example: PRH9-22LP

All PhaseRaiser® steel Units include mounting hardware, caps, and side shields.


IMPORTANT PHASERAISER® FIELD INFORMATION

The owner should provide the pole circumference measurement taken at 48" above ground to ensure that proper bolt and threaded rod lengths are supplied by LWS.


LWS reserves the right to refuse any returned material if pole measurements are not provided as specified above. When measurements are not provided, LWS will reference ANSI 05.1-2017 Pole Dimensions to determine bolt and rod lengths. Based on these estimated dimensions, the customer will be responsible for any material and delivery costs of replacement bolts and rods.



H-Frame Structures



Single Pole Structures



USE THE PHASERAISER® WIZARD WITH PLS-CADD™ TO SIMULATE RAISING CONDUCTOR CLEARANCES

The PLS-CADD PhaseRaiser Wizard allows users to easily and accurately model the effects of a PhaseRaiser installation on each specific structure as well as the adjacent structures.







Materials, Equipment & Manpower Required for Typical Installations

PhaseRaiser® units are made of high strength galvanized steel. All bolts conform to ANSI C135.1

The PhaseRaiser® units are also available in painted and weathering steel.

Materials





Personnel

The PhaseRaiser® system enables a crew as small as **three** for single pole or a crew of **five** for H-frame structures to cut the existing poles, install custom designed galvanized or painted steel PhaseRaiser® units, then raise and secure the structure to the desired height up to an additional twenty feet.

LWS Field Support - A skilled field trainer from LWS works with qualified lineworkers until they develop a comfortable skill level - normally after raising two to three structures.

Equipment




The PhaseRaiser® system requires specialized training, tools and equipment for installation. This equipment is available for purchase or rent and includes on-site training by LWS field personnel as well as the following specialized tools and equipment:

- Custom Equipment Trailer w/ Tool Boxes
 - Hydraulic Lifting Unit
 - Hydraulic Hoses
 - 4" x 8' Hydraulic Cylinders
 - 4" x 14' Hydraulic Cylinders
 - Cylinder Extensions
 - Galvanized Lifting Vangs
 - Cylinder Pins
 Nylon Ratchet Straps
 - Banding Dispenser
 Banding Shear
 - Drilling Alignment Tools
 - 4' Working Ladders

In addition to the equipment trailer, a line or boom truck, chain saw and air compressor are also needed.

Skid Mounted Hydraulic System

For use in remote access areas or environmentally sensitive locations where conventional equipment cannot be used. Additional tools are





INCREASE POLE STRENGTH WITH PRS POLE RECLASSIFICATION SYSTEM®

With Patented Features

The PRS system is the perfect solution when existing poles are, or will be, loaded beyond their original design strength with the addition of assets or system hardening. The system incorporates a lower driven steel unit and an upper steel unit that is cross bolted to the pole. When the PRS is used on steel or concrete poles, the upper unit is banded with high strength banding. Reclassifying existing poles with the PRS saves thousands of dollars versus pole changeouts. LWS engineers will specify the appropriate PRS units based upon the existing pole size and desired loading information provided.





INCREASEEXISTING POLE CLASS

- EXTEND LIFE OF EXISTING POLES
- AVOID COSTLY OUTAGES


Components of the PRS System







The patented design of the PRS steel unit gives it significant transverse strength, allowing it to be installed at 45° in either direction around the pole to accommodate risers and other existing attachments.



PRS Unique Patented Features


The PRS system utilizes the patented features of the PoleEnforcer® groundline reinforcement system.

As the lower steel units are driven into the ground, the full length taper design

forces the full length flanges to maintain contact with the pole below the groundline. This ensures that the increased load is properly transferred to the pole butt and soil.

PRS upper units incorporate a full length flange. Depending on the design, the upper units can either be tapered or straight.

PATENT NO. 5,383,749






PRS Engineering Worksheet

The LWS engineering staff will assist you in determining which standard PRS configuration will best suit your needs. Complete structural engineering analysis including foundation design is provided at no extra cost. Just fill in the requested information on this page along with a sketch of your current configuration and send to **engineering@lwsinc.com**. OR you may fill out this form online by visiting **www.lwsinc.com**.


Customer Name Contact Name Project Name _____ Project Address _____ Delivery Address _____ Construction Type _____ Number of Conductors _____ Conductor Size _____ Underbuild Conductor Size Underbuild Number of Wires _____ Number of Neutral/Shield Wires Cable TV ___ No. of Wires _____ Telephone ___ Diameter ____ No. of Wires ____ Neutral/Shield Wire Size _____ _____ to____ Loading Conditions Example - NESC Heavy Loading, Grade B Construction, Extreme Wind Pole Height, Range ______ to_____ Pole Class ______ Soil Type _____ Age of Line ____ ______ Leaners ___Yes ___No

Please attach your standard drawing(s) which include the required information as shown below:





PRS TECHNICAL DATA



Modeling LWS Steel Reclassification Units (PRS) in PLS-Pole


Step 1.

Add global joint "Grnd" at the groundline as shown below.

Menu Tab: Geometry - Joints

The location of this joint should be offset from the pole centerline a distance equal to 1/2 the pole diameter at the groundline in the direction of the location of the unit. Generally speaking, this is on the longitudinal pole face.

X, Y, & Z Disp. Rest. as well as X, Y, & Z Rot. Rest. should all be fixed.



Step 2.

Add attachment label "Prst" at the estimated height of the top of the PRS unit as shown below.

Menu Tab: Geometry - Wood Poles - Attach. Labels

	Joint Label	Distance From Origin/Top Joint (ft)	Global Z of Attach (ft)	Hole Diameter (in)	Hole ^Azimuth (deg)
1	P:S	0.83333333	0	0.6875	0
2	P:C	8.75	0	0.8125	0
3	P:L	16.75	0	0.8125	0
4	P:R	24.75	0	0.8125	0
5	P:F1-F0	31.5	0	0.6875	90
6	P:F1-F1	34	0	0.6875	90
7	P:Prst	36.5	0	0	0
8					



Step 3.

Add PRS and PRS "Offset" properties to the crossarm component table.

Menu Tab: Components - Crossarms

The PRS "Offset" properties should be sufficiently rigid (infinitely stiff) to effectively transfer load between the pole and the top of the PRS unit. This member allows PRS to be applied at the face of the pole in any desired direction. Generally speaking, that is on the longitudinal pole face. Length of the offset should be equal to 1/2 the pole diameter at the top of the PRS unit.

Properties of the PRS unit itself (as well as the PRS "Offset" if desired) will be provided by LWS.

	Cross Arm	Stock	Cross	X	Z	Weight	Depth	Width	Length	Modulus
	Property	Number	Section	Inertia	Inertia					of
	Label		Area							Elasticity
			(in^2)	(in^4)	(in^4)	(lbs)	(in)	(in)	(ft)	(ksi)
1	Offset		1	1000	1000	1	1	1	0.5625	29000
2	PRS49-20		3.57	43.94	43.94	243	8.375	8.375	20	29000

Step 4.

Attach the PRS "Offset" and PRS unit to the pole by adding a crossarm entry.

Menu Tab: Geometry - Crossarms

The azimuth of the PRS "Offset" should be in the direction of the pole face on which the PRS unit is being applied. Generally speaking, this is the longitudinal face. This should coincide with the location of joint "Grnd" at the groundline.

											<u> </u>
	Pole	Tip	Base	X of	Y of	Z of	Inclin.	Inclin.	Wood Pole	Material	Attach.
	Label	Joint	Joint	Base	Base	Base	About X	About Y	Property Set	Property Set	Labels
				(ft)	(ft)	(ft)	(deg)	(deg)			
1	P			0	0	0	0	0	WC-2-65	WC-Western Red Cedar	Edit (7 points)
2											
									•	`	



Connect PRS "Offset" to wood pole label "Prst". Connection codes should be fixed.

	Attach	Offset	Connect	Connection
	Label		At	Code
		(ft)		Туре
1	Offset:0	0.000	P:Prst	Fixed
2	Offset:E	0.563		Fixed

Connect PRS unit to Joint "Grnd" and end of PRS "Offset". Connection codes should be fixed.


	Attach	Offset	Connect	Connection
	Label		At	Code
		(ft)		Type
1	PRS:0	0.000	GrndP	Fixed
2	PRS:E	20.000	Offset:E	Fixed

Step 5.

Adjust the PRS unit length and strength as necessary


To adjust length:


- A. Change the "Global Z" dimension of the "Prst" label in the wood pole at atachment label table to the desired location.
- B. Select a PRS unit length that cor responds to the new "Global Z" dimension.
- C. Component information for other PRS units can be supplied by LWS upon request if other strength ratings are required.



WEBSITE

INSTALLATION VIDEOS





ADDRESS

1327 285th RD - PO Box 386 Seward, Nebraska 68434 PHONE

800-949-3526

WEB

www.lwsinc.com sales@lwsinc.com